

Pressure Measurements

Experimental Methods for Engineers

Sebastiano Lazzi Gazzini, LEC,
lazzi@lec.mavt.ethz.ch



Overview

- Total and static pressure
 - Boundary layer
- Static Pressure Tappings
- Pressure measurement techniques
 - Pitot tube
 - Pneumatic Probe
 - Fast Response Aerodynamic Probe (FRAP)
- Example

P_{tot} measurement required for efficiency

- P_{tot} is constant in a flow without work transfer (no friction, no heating)
- P_{tot} is a direct measure of efficiency → Need to know P_{tot} to calculate machine's efficiency:

$$\eta_{Compressor} = \frac{\left(\frac{P_{tot,ex}}{P_{tot,in}} \right)^{\frac{\gamma-1}{\gamma}} - 1}{\frac{T_{tot,ex}}{T_{tot,in}} - 1}$$

$$\begin{aligned} P_{tot,ex} &> P_{tot,in} \\ T_{tot,ex} &> T_{tot,in} \end{aligned}$$

$$\eta_{turbine} = \frac{\frac{T_{tot,ex}}{T_{tot,in}} - 1}{\left(\frac{P_{tot,ex}}{P_{tot,in}} \right)^{\frac{\gamma-1}{\gamma}} - 1}$$

$$\begin{aligned} P_{tot,ex} &< P_{tot,in} \\ T_{tot,ex} &< T_{tot,in} \end{aligned}$$

$$P_{\text{tot}} = P_S + P_{\text{dyn}}$$


- Total pressure = static pressure + dynamic pressure

$$P_{\text{tot}} = P_S + \frac{1}{2} \cdot \rho \cdot V^2$$

ρ = fluid density
 V = fluid velocity


- Static pressure is equal to total pressure, if $V = 0\text{m/s}$.
- Different names for the same thing:
 - stagnation pressure = total pressure
 - $P_{\text{tot}} = P_0$
 - Dynamic head = dynamic pressure

P_{tot} and P_s in Boundary Layer




- Static pressure travels through a shear layer such as Boundary Layer
- A perpendicular hole on a surface wall measures P equal to the centre of the field

Static Pressure Tappings




Static pressure tapping
parallel to the flow

- Tappings on solid wall
- Local velocity zero
- Any pressure measurement on the wall is **static**




- Tapping inclination affects accuracy
- Ideally perpendicular to wall surface

Static Pressure Tapping manufacturing




- Drill from both sides
- Connect tube (one side)
- Small hole (other side)



Whistling hole

- Accuracy in location
- Avoid unsteady effect / interactions
- Improve stability

Pressure measurement



Pressure can be calculated using Pascal's law:

$$\Delta P = \rho \cdot g \cdot \Delta z$$

Challenges:

- 1 bar corresponds to ~10m of H₂O
→ Limited range
- **Poor dynamic response**

Liquids used:

- Water
- Alcohol
- Quicksilver (Historic!)




→ Today, commercial products are used to measure the pressure (Keller, Scanivalve, etc.)

Total pressure measurement: Pitot tube

Total pressure is more difficult to be measured:



- Need to reduce the flow velocity to zero: $V=0\text{m/s}$
- Use stagnation point

Pitot tube:




$$V = \sqrt{\frac{2(P_{tot} - P_s)}{\rho}}$$

Pitot Tube: Where to put the static pressure holes?



5-Hole Probe




$$P_{ave} = \frac{P_2 + P_3 + P_4 + P_5}{4}$$

$$\Delta P = P_2 - P_3 \rightarrow \alpha$$

$$\Delta P = P_4 - P_5 \rightarrow \beta$$

$P_1 = P_0$ when probe is aligned with flow

$P_{ave} \neq$ static pressure, but an approximation



5 Hole Probe Calibration



$$\frac{P_2 - P_3}{P_1 - P_{ave}} \rightarrow \beta$$

$$\frac{P_4 - P_5}{P_1 - P_{ave}} \rightarrow \alpha$$


$$\frac{P_{tot} - P_1}{P_1 - P_{ave}} \rightarrow K_{tot}$$

$$\frac{P_{tot} - P_S}{P_1 - P_{ave}} \rightarrow K_{static}$$

Non dimensionalizing
using any Δp




4 Hole Probe




- 4 Hole Probe has a different tip shape
- Reduced pitch sensitivity (no P5)
- Other pneumatic probes:
 - 7HP
 - Multihole

Time resolved measurements: FRAP


- FRAP = **F**ast **R**esponse **A**erodynamic **P**robe
- Probe has two holes:
1 yaw hole (for yaw angle sensitivity) and
1 pitch hole (for pitch angle sensitivity)
- Piezo resistors on membranes directly at the holes
- Deformation of membranes \sim pressure signal
- Enables time resolved measurements
- Calibration analogue to pneumatic probes




Unsteady measurement example



- Stator Relative total pressure measurement at the exit of turbine rotor
- Measured with FRAP
- Blade passing frequency = 2430Hz





Laboratory: Intrusive Probe Measurement Technique in Turbomachinery




→ Pressure measurements at the exit of an axial compressor using 5HP

Laboratory: Intrusive Probe Measurement Technique in Turbomachinery




Stator

Laboratory: Intrusive Probe Measurement Technique in Turbomachinery



Conventional
Way of Plotting
Velocity
Triangles



→ Velocity Triangles

Laboratory: Intrusive Probe Measurement Technique in Turbomachinery

- Post Process the data with **MATLAB** and present the following flow parameters:
 - P_{tot} , P_{stat}
 - Mach number
 - Yaw angle, Pitch angle
 - Velocities V_x , V_r , V_Θ
- The data should be presented in two main forms:
 - 2D plots over the pitch
 - mass averaged plots over the span
- Produce Velocity Triangles

